

ASSEMBLY INSTRUCTIONS


20013-2 - Garden sofa Vistdal

PARTS AND HARDWARE


Avoid using sharp objects such as a knife to cut open packing as you may accidentally damage the upholstery.



A:1PC



B:1PC



E:1PC



G:2PCS



M6*20

N:4 PCS



Q:1PC

Do not fully tighten bolts until assembly is complete.
Assemble the sofa leg(B) to the seat(A), using bolt and washer(N).

