

Alarm Clock Instructions

Care & Instruction Manual

PLEASE READ THESE INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE REFERENCE

Warnings

- ⊠ Keep out of reach of children.
- ⊠ Batteries should only be installed by an adult.

ACTIVATING THE CLOCK


Insert 1 x new AA (1.5V) batteries into the battery compartment, taking care to observe the correct polarity. Before setting the time and alarm, please rotate the hands a full 12 hours before setting.

TIME SETTING

To set the clock to the desired time, rotate the "Time Set Knob" on the back of the clock in an anti-clockwise direction until the correct time is reached.

ALARM SETTING

- To set the alarm, rotate the "Alarm Set Knob" on the back of the clock in an anti-clockwise direction to the desired alarm time.
- To activate the alarm, move the "Alarm ON/OFF" switch to the ON position – please note the alarm will sound at both AM and PM times when the switch is in the ON position.
- To de-activate the alarm, move the "Alarm ON/OFF" switch to the OFF position.



Care instructions

- ⊠ Wipe the clock with a soft dry cloth only.
- ⊠ Replace the battery every 12 months or when the clock stops.

Battery safety & disposal

- ⊠ Dispose of any used batteries responsibly by taking it to your local authority household waste recycling facility.
- ⊠ Don't dispose of batteries in a fire as they may explode.
- ⊠ This clock will only take 'AA' 1.5V batteries in this clock.
- ⊠ Make sure you've inserted the batteries correctly, so you have the correct polarity (+ and -). You should only use batteries that are the equivalent of those recommended above. Don't use rechargeable batteries with this item. And never mix old and new batteries, change them at the same time.

